

HYDROGEN PEROXIDE & PERACETIC ACID KIT

DROP COUNT
CODE 7191-02

QUANTITY	CONTENTS	CODE
30 mL	*Sulfuric Acid, 1:1	*6141WT-G
15 mL	Ferrioin Indicator	6410-E
2 x 30 mL	*Hydrogen Peroxide Titrant	*5650LWT-G
30 mL	Potassium Iodide 20% Solution	6521-G
60 mL	Peracetic Acid Titrant	S-6155-H
1	Test Tube, 5-10-25 mL, plastic, w/cap	0715
1	Pipet, 0.5 mL, plastic	0353

*WARNING: Reagents marked with an * are considered to be potential health hazards. To view or print a Safety Data Sheet (SDS) for these reagents go to www.lamotte.com. Search for the four digit reagent code number listed on the reagent label, in the contents list or in the test procedures. Omit any letter that follows or precedes the four digit code number. For example, if the code is 4450WT-H, search 4450. To obtain a printed copy, contact LaMotte by email, phone or fax.

Emergency information for all LaMotte reagents is available from Chem-Tel: (US, 1-800-255-3924) (International, call collect, 813-248-0585)

To order individual reagents or test kit components, use the specified code number.

NOTE: Do not use for tapwater or less than 20 ppm peracetic acid.

PROCEDURE

HYDROGEN PEROXIDE

1. Fill test tube (0715) to 10 mL line with sample water.
2. Add 10 drops of *Sulfuric Acid, 1:1 (6141WT). Swirl to mix. Make sure solution is thoroughly mixed.
3. Add 1 drop of Ferrioin Indicator (6410). Swirl to mix. Make sure solution is thoroughly mixed. Solution will turn pale orange-pink if hydrogen peroxide is present.
4. While gently swirling tube, add *Hydrogen Peroxide Titrant (5650LWT) one drop at a time until pale orange-pink color changes to colorless or pale yellow. Make sure solution is thoroughly mixed. Count the number of drops added. Hold bottle vertically.
5. Discard titrated sample and rinse tube out with sample water.
6. Multiply the number of drops used in Step 4 by 50 (fifty). Record as ppm Hydrogen Peroxide.

PERACETIC ACID

NOTE: This method may be used to test low to high concentration of peracetic acid. Choose the procedure that is most appropriate for the sample being tested.

1 drop = 15 ppm

1. Fill test tube (0715) to 10 mL line with sample water.
2. Add 10 drops of *Sulfuric Acid, 1:1 (6141WT). Swirl to mix. Make sure solution is thoroughly mixed.
3. Add 1 drop of Ferroin Indicator (6410). Swirl to mix. Make sure solution is thoroughly mixed.
4. Add 1 drop of Potassium Iodide 20% Solution (6521). Swirl to mix. Make sure solution is thoroughly mixed. Solution will turn a cloudy brown if peracetic acid is present.
5. While gently swirling tube, add Peracetic Acid Titrant (S-6155), one drop at a time until brown color changes to a clear, pale orange-pink which persists for 20 seconds. Make sure solution is thoroughly mixed. Count the number of drops added. Hold bottle vertically.
6. Multiply the number of drops used in Step 5 by 15 (fifteen). Record as ppm Peracetic Acid.

For example:

10 drops x 15 = 150 ppm Peracetic Acid

Low Range [20-90 ppm] 1 drop = 6ppm

Fill the test tube to the 25 mL line. Follow the test procedure and use 25 drops of *Sulfuric Acid, 1:1 (6141WT), 3 drops of Ferroin Indicator (6410) and 3 drops of Potassium Iodide 20% Solution (6521). In Step 6 multiply the number of drops used by 6 (six). Record as ppm Peracetic Acid.

For example:

10 drops x 6 = 60 ppm Peracetic Acid

High Range [300-500 ppm] 1 drop = 300 ppm

For higher concentrations of peracetic acid use the 0.5 mL pipet (0353) to add 0.5 mL of the sample to the test tube (0715). Fill the tube to the 10 mL line with hydrogen peroxide/peracetic acid-free water. Follow Steps 2 - 5. In Step 6 multiply the number of drops used by 300 (three hundred). Record as ppm Peracetic Acid.

For example:

10 drops X 300 = 3000 ppm Peracetic Acid



Yalitech Instruments

Santiago de Chile, Río Refugio 9648, Parque de Negocios ENEA, Pudahuel.

www.yalitech.cl · ventas@yalitech.cl · (+56 2) 28988221