



50 ppm



100 ppm



200 ppm



400 ppm

## QAC QR TEST STRIPS

CODE 2951 • 100 STRIPS

1. Immerse pad in solution and remove immediately.
2. Hold strip level for 5 seconds. Shake off excess water from pad. Compare pad to color chart above.

**NOTE:** Sample must be at room temperature (above 75°F).  
If testing Hyamine 1622, change dip time to 45 seconds in Step 1.

Keep out of sunlight.

Keep vial closed when not in use.



PO BOX 329 • CHESTERTOWN • MARYLAND • 21620 • USA  
410-778-3100



6 37395 03597 5