

Code 2964-G



Free Chlorine
25 Test Strips



Insta-Test[®] ANALYTIC



Using a cup-size sample, dip strip for **2 seconds**. Remove strip with **pad face up**. **DO NOT SHAKE OFF EXCESS WATER**. With pad still facing up, read immediately. Discard strip after 30 seconds.



- Keep wet fingers out of the bottle.
- Cap bottle tightly after removing strip.
- Store in a cool, dry place.

Note: Pad may appear light pink when strip is removed from vial. Pad color will not affect reacted test results.



LaMotte Company, Chestertown, MD 21620
<http://www.lamotte.com>

