

Nitrite & Nitrate

50 Test Strips



Insta-Test[®] ANALYTIC

| | | | | | | | |
|----------|--|--|--|--|--|--|--|
| Top pad: | Nitrite as NO ₂ -N ppm | | | | | | |
| | Next pad: | Nitrate as NO ₃ -N ppm | | | | | |



Using a cup-size sample, immerse strip for **2 seconds** and remove with **pads face up. DO NOT SHAKE OFF EXCESS WATER. Wait 60 seconds and immediately compare** to color chart.



- Keep wet fingers out of the bottle.
- Cap bottle tightly.
- Store in a cool, dry place.



LaMotte Company
802 Washington Ave., Chestertown, MD 21620 USA
410-778-3100 • www.lamotte.com

