


Alkalinity
50 Test Strips

LaMotte

Insta-Test[®] ANALYTIC



Using a cup-size sample,
dip strip for **2 seconds**.

Remove strip with **pad face up**.

DO NOT SHAKE OFF EXCESS WATER. With pad still facing up, read immediately. Discard strip after 30 seconds.



*View from
above.*

LaMotte Company,
Chestertown, MD 21620
<http://www.lamotte.com>

- Keep wet fingers out of the bottle.
- Cap bottle tightly after removing strip.
- Store in a cool, dry place.

