




Immerse strip. SWIRL 3 times*. Remove with pads face up. DO NOT SHAKE OFF EXCESS WATER. Wait 10 seconds for Alkalinity color to develop then read results: Alk>pH>Copper

*In cup-size sample, swirl 5 times.





ppm рH 6.8 Purple color indicates excessive sanitizer

Copper Copper 3.0 0 0.3 0.6 1.0 ppm Code 3001-G



Rio Refugio 9648 - Parque de Negocios ENEA, Pudahuel, Santiago ~ CHILE

Tel. +56 2 28988221 • www.yalitech.cl

- out of the bottle.
- Close cap tightly after removing
 - In pools, immerse strip to a depth of 12"-18" and swirl 3 times.
 - In spas, turn off jets and immerse strip to a depth of 6 below the surface and swirl 3 times.
 - For best results read in natural davlight.
 - Store in a cool, dry place.

