



Code 3002

High Range Chlorine Dioxide 50 Test Strips

YallTech Instrumente
Savannah, GA
www.yalltech.com

Insta-Test[®] ANALYTIC

High Range Chlorine Dioxide



Using a cup-size sample,

immerse strip for **2 seconds**.

Remove strip with **pad face**

up. DO NOT SHAKE OFF

EXCESS WATER. With pad

still facing up, **wait 10 seconds**

and read the

strip. Discard strip after

30 seconds.

LaMotte Company

Chestertown, MD 21620

www.lamotte.com



!Keep wet fingers
out of the bottle.


!Cap bottle tightly.

!Store in a cool, dry
place.

!In concentrations
greater than 500

ppm the pad will be
a mottled color of

golden-brown and
black.



*View from
above.*

Made in
USA

