


Immerse strip for **2 SECONDS**. Remove with **pads face up**. **SHAKE ONCE TO REMOVE EXCESS WATER**. Read immediately:  
FCI > Alk > pH > CyA

<b>FCI</b> Free Chlorine ppm						
	0	0.5	1	3	5	10
<b>Alk</b> Alkalinity ppm						
	0	40	80	120	180	240
<b>pH</b>						
	6.2	6.8	7.2	7.8	8.4	9.0
Purple color indicates excessive sanitizer						
<b>CyA</b> Cyanuric Acid ppm						
	0	40	100	150	250	

For best results, pH must be between 7.0-8.4



View from above.

- Keep wet fingers out of the bottle.
- Close cap tightly after removing strip.
- In pools, immerse strip to a depth of 6".
- In spas, turn off jets and immerse strip to a depth of 6".
- For best results read in natural daylight.
- Store in a cool, dry place.



YaliTech  
INSTRUMENTS  
FUND. 1982

Code 3032

Made in

USA



Rio Refugio 9648 - Parque de Negocios ENEA, Pudahuel, Santiago  
~ CHILE

Tel. +56 2 28988221 • [www.yalitech.cl](http://www.yalitech.cl)

