



DIAL THERMOMETER



Operating Instructions

INSTRUMENT OPERATION - Insert the probe into the liquid being measured, the instrument reading will take a few seconds to stabilise.

FR - FONCTIONNEMENT DE L'INSTRUMENT
Insérer la sonde dans le liquide à mesurer, la lecture prend quelques secondes pour se stabiliser.

DE - GEBRAUCHSANWEISUNGEN
Den Sensor in die zu messende Flüssigkeit stecken. Der am Gerät angezeigte Messwert stabilisiert sich nach ein paar Sekunden.

IT - FUNZIONAMENTO DELLO STRUMENTO
Inserire la sonda nel liquido da misurare. Il dispositivo potrebbe impiegare alcuni secondi per stabilizzare la lettura.

PT - MANUSEAMENTO DO INSTRUMENTO
Introduzir a sonda no líquido a analisar, a leitura do aparelho poderá levar alguns segundos a estabilizar.

ES - FUNCIONAMIENTO DEL INSTRUMENTO
Insertan la punta de prueba en el líquido que es medido, la lectura del instrumento tomarán algunos segundos para estabilizarse.

CALIBRATION ADJUSTMENT - Caution: Do not adjust unless certain the instrument is out of specification. Compare against a reference thermometer/Ice Bath. Using the spanner, twist the lock-nut whilst holding the dial to correct any error. For further instructions, refer to the ETI website: etiltd.com/cal-adjustment.

GUARANTEE - This instrument has a one-year limited guarantee against manufacturing defects. Full details of liability are available at: etiltd.com/terms.

Product code	Range
800-801	-40 to 70 °C
800-802	-10 to 110 °C
800-803	0 to 250 °C

